



1. Mark the fixing positions and drill holes to suit the anchors, make sure that the drilled holes are level.
2. Install the anchors and the mounting brackets, then secure with screws.
3. Install the hook to the mounting bracket. Tighten set screws with Allen key.

