


Installation Steps

Installation Precautions

- 1、 The valve body has been inspected and debugged by the factory. Please do not disassemble it, so as not to affect the performance.
- 2、 Before installing the faucet, please remove impurities and sludge in the embedded pipe to prevent blockage and affect the performance.
- 3、 After installation, please open the water source and check whether the connections are tight enough to ensure no leakage.
- 4、 The medium temperature should not be greater than 90 degrees Celsius.
- 5、 The torsion of the nut joint shall not be greater than 10Nm.



Product Size Chart

